
TG SERIES SEAL KIT OR REBUILD KIT FOR UNITS WITH DIRECT MOUNT PUMP FLANGE

Examine the under side of the hydraulic mounting flange. If there is an o-ring groove as shown then use the o-ring 12T36751 provided in the kit. If groove is not present, then use the 2nd gasket provided (13T38542).

Lubricate seals and o-rings prior to installation. Place the o-ring around the output shaft bearing which protrudes from the housing before installing the output flange.



NO GROOVE IN FLANGE (USE 13T38542 GASKET)

GROOVE FOR O-RING (USE 12T36751 O-RING)



IN04-02 Printed in the U.S.A. © Muncie Power Products, Inc. 2004 Muncie Power Products, Inc. Member of the Interpump Hydraulics Group General Offices and Distribution Center • P.O. Box 548 • Muncie, IN 47308-0548 (765) 284-7721 • FAX (765) 284-6991 • E-mail info@munciepower.com Web site http://www.munciepower.com

Drive Products, Inc., Toronto, Exclusive Agents for Canada, ISO Certified by an Accredited Registrar



